

# KIVO PLUS

## Child-parent tricycle tandem



The Kivo Plus is a child-parent tricycle tandem with a grown-up sitting behind and a child sitting in front. The child can get a good view of the environment. The rider sitting behind can always keep a good watch on the child. The Kivo Plus has a low step through and therefore, is easier to use. Equipped with two rear wheels instead of one, the Kivo Plus trike provides more stability. Because of these two wheels it becomes more easy to get on and off of the bike when its standing still. Normally the Kivo has 8 gears and a freewheel switch.

You can use the switchable freewheel to determine whether and how the passenger pedals. The Kivo also has a variant with two wheels behind. An optional electric engine is possible to install on all the variants, which gives a comfortable pedal support, this makes cycling on this tandem even easier.

### SUITABLE FOR:

Children, who cannot cycle independently and want to participate in a journey with an attendant.

### TECHNICAL SPECIFICATIONS

Inside leg length*	F 77 - 89 cm R 50 - 62 cm
Frame height*	F 52 cm, R 30 cm
Step through height	F 45 cm, R 36 cm
Cycle weight	+/- 48 kg
Cycle length	246 cm
Cycle width	75 cm

\* adjustable



Detachable  
frame



Steering  
backside



Switchable  
freewheel